## **ASSEMBLY AND**

### <u>.IGHTING</u>

## INSTRUCTIONS

**ZUBRI Z1-12** 

gas/propane cylinders. and must be read before using the Zubri Z1-12 patio heater or handling described in the Zubri SAFETY GUIDE Important safety precautions are This is a quick guide

### FOR ASSISTANCE FREE

# ASS IVB REMOVE ALL PARTS FROM BOX OR CARRY CAS

STEP 2

### STEP 1



NB: This step is not necessary if the heater is case. supplied in a carry

### TO BURNER ATTACH EMITTER

HEAD Stand body (b

burner head b(i emitter (a) on upright. Place


is attached firmly to burner head b(i). wing nut c(i) onto "u" bracket (c) until hand tight and emitter (a) burner head b(i). Secure U bracket onto burner head by tightening Place "u" bracket (c) inside emitter (a). Insert threaded rod c(ii) through hole in "u" bracket (c) and screw into hole in top of

slide leg into leg holder on control cone NB: make sure clutch spring d(i) locks hole in leg holder.

ATTACH LEGS TO CONTROL CO

Depress clutch spring d(i) on leg (d)

### STEP 3



c(iii) and slide nut c(iii) the folding wing emitter (a). Unfold reflector onto folding wing nut of reflector (t) over Place centre hole A T T A C H

onto emitter.

OVER TIGHTENING THE FOLDING WING NUT CAN DAMAGE THE REFLECTOR.

STEP 4




screw down onto the reflector (f) until reflector is held firmly and

ATTACH SKIRT

Wrap skirt around legs. Secure with v at top. Zip up. Move skirt so that zip down one of the legs

# CONNECTING THE GAS / PROPANE CYLINDE



HANG GAS / PROPANE CYLINDER

onto hook so cylinder is suspended. WARNING: Cylinders are Lift gas / propane cylinder

important weight to the Zubri heater and helps to keep it stable. heavy & may cause injury. IMPORTANT: Cylinder adds

Fix gas regulator to cylinder. Make sure regulator is securely fitted.



## LIGHTING THE HEATER

STEP 1 TURN ON GAS SUPPLY FROM GAS / PROPANE CYLINDER

STEP 2



**POSITION FLAME**Hold flame under burner head (bi) as indicated above.



START GAS FLOW

Push in control knob and turn anticlockwise.

### GAS WILL IGNITE

# IMPORTANT: KEEP CONTROL KNOB PUSHED IN FOR AT LEAST 15 SECONDS.

This will allow the safety thermo couple devise to heat up. If the thermocouple is not heated correctly the gas supply will automatically cut off.

NB: If flame goes out for any reason wait 2 minutes and repeat step 2 + 3.

**TO ADJUST HEAT** – Push in control knob and turn anticlockwise to increase heat or clockwise to reduce heat.

**TURN HEATER OFF + MAKE SAFE** By pushing in control knob and turning clockwise until stop. Flame will go out. TURN OFF gas supply on gas/propane cylinder.